




PARTS KEY:




Tub Shelves*
(SEC, EC, STC, and TC models)




Flat Shelves*
(BC, HE, HC, LE, LP, and WT models)



4" Standard Casters
(All models except for ECHD and XLC)



5" Heavy-Duty Casters + Hardware
(ECHD and XLC models)



Square Legs
(WT, SEC, and EC models)




Round Legs
(LE, LP, STC, TC, and BC models)



Fluted Legs
(XLC and all models with cabinet pack)

REQUIRED TOOLS:




IMPORTANT:

If your cart includes options such as a power strip, pullout shelf, locking drawer, or locking cabinet, installation instructions for those components will be included in their packaging.


*NOTE:

Some BC, STC, and TC models come with a mix of flat and tub shelves.


OPTIONAL ACCESSORIES: (If your cart includes one or more of the optional accessories shown below, separate installation instructions are enclosed with each accessory.)




Cabinet Pack




Pullout Shelf + Hardware



3-Outlet Power Strip + Hardware



3-Outlet Power Strip with Cord Wrap + Hardware




Locking Drawer + Hardware

WHAT'S IN THE BOX:

Part	Standard 2-Shelf	Standard 3-Shelf	Standard 4-Shelf	Standard 5-Shelf	Standard 6-Shelf	Heavy-Duty 2-Shelf	Heavy Duty 3-Shelf
Top Shelf (A)	1	1	1	1	1	1	1
Bottom Shelf (B)	1	1	1	1	1	1	1
Middle Shelf (C)	0	1	2	3	4	0	1
Locking 4" Caster (D)	2	2	2	2	2	0	0
Non-Locking 4" Caster (E)	2	2	2	2	2	0	0
Locking 5" HD Caster (F)	0	0	0	0	0	2	2
Non-Locking 5" HD Caster (G)	0	0	0	0	0	2	2
Allen Wrench (H)	0	0	0	0	0	1	1
Threaded Insert (I)	0	0	0	0	0	16	16
Threaded Screw (J)	0	0	0	0	0	16	16
Star Washer (K)	0	0	0	0	0	16	16
Legs (L)	4	8	12	16	20	4	8

ASSEMBLY INSTRUCTIONS:


Standard Models



NOTE: Position locking casters (D) on the same end as the handle.

Flip unit upright after casters are securely installed.


Heavy-Duty Models



NOTE: Position locking casters (F) on the same end as the handle.

Flip unit upright after casters are securely installed.

Cabinet Pack Models



1a IMPORTANT: Flip shelf (B), and lock the 2 locking casters (D) before assembling the unit.

2 NOTE: Install fluted legs (L) to bottom shelf with slots facing inward.

Stop Here! Refer to cabinet assembly instructions, then proceed to step 3.

NOTE: Position the handle on the same end as the locking casters (D).