



BLUETOOTH 4.0 FTMS  
Connects to 3<sup>rd</sup> Party Apps



#### OPTIONAL EQUIPMENT

Extended Handrails  
TV Bracket (TV not included)

The CT800 commercial treadmill has a reputation for reliability and value that meets your space and budget needs. Weighing in at 360 lb and backed by an impressive warranty, this machine is truly heavy-duty and packs a load of premium features that keep clients happy. The top control panel boasts a simple and intuitive design with direct speed and incline buttons, multiple storage options for water bottles, phones, and other accessories, as well as a built-in fan that helps keep users cool. The ergonomically positioned hand pulse sensors let users easily monitor vital stats, while a variety of built-in programs allow nearly endless workout customization to suit a wide range of fitness levels.

## CT800 TREADMILL

- Bright white multi-window LED console is easy to read and simple to use
- Direct speed and incline buttons make workouts more efficient
- Contact and wireless heart rate options to help keep clients in their safe and effective training zone
- Dual-drive motor cooling fans to protect and extend the life of the motor and control board
- Maintenance-free deck system provides hassle-free use for thousands of miles
- Spacious 22" x 60" running deck to accommodate users of all sizes
- Multi-ply commercial belt for superior belt life



## CT800 CONSOLE FEATURES

The electronics in the CT800 are designed to provide simple and intuitive operation. The console features a large easy-to-read display with a variety of program options for users of all fitness levels, an integrated fan to keep clients cool, and a USB port with multiple storage tray options to help keep their devices charged. The addition of direct speed and incline buttons make all workouts more efficient and interval training workouts a breeze.

### EQUIPMENT SPECIFICATIONS

<b>Console</b>	white multi-window LED displays (18-character message center, profile matrix, incline, and speed), direct incline and speed buttons, cooling fan, USB charging port, Bluetooth FTMS (connects to fitness apps), C-safe
<b>Programs</b>	manual, interval, 5k, 10k, HIIT, hill, fat burn, cardio, Gerkin Protocol Fit Test, 6 military readiness tests (Army, Navy, Air Force, Marines, PEB, Coast Guard), 2 HR, custom
<b>Heart Rate</b>	contact and Bluetooth compatible (chest strap sold separately)
<b>Speed/Incline</b>	0.5 – 12 mph / 0 – 15%
<b>Power</b>	120 volts (NEMA 5–15P electrical cord); 15-amp circuit recommended
<b>Drive Motor</b>	4.0 HP DC drive with grade H insulation
<b>Deck</b>	maintenance-free, 1" thick, double-sided
<b>Belt</b>	22" x 60", commercial multi-ply
<b>Rollers</b>	commercial grade 3.0"
<b>Storage</b>	reading rack, cell phone ledge, large water bottle storage, and multiple accessory trays
<b>Frame</b>	heavy-gauge high-strength steel with durable powder-coat paint
<b>Dimensions</b>	85" L x 36" W x 61" H
<b>Product Weight</b>	380 lb
<b>Max User Weight</b>	450 lb
<b>Options</b>	extended handrails, TV bracket

### WARRANTY INFORMATION

**Commercial Warranty (Non-dues Paying Facilities)** – Lifetime frame, 5 years motor, deck and parts, and 2 years labor