BASELINE EVALUATION INSTRUMENTS

plastic 8-inch 360° Hi-Res® goniometer instructions for use





Intended Purpose: permits observation of joint's axis of motion, and range of motion

- · Permits observation of joint's axis of motion, and range of motion
- 360° head has three scales for ease of use
- Primary scale reads in 1° increments
- Goniometer arm has a linear scale in inches and centimeters
- Goniometer arm remains at measurement until reset

other goniometer styles and sizes available:

12 inch 360°	12-1000*
8 inch 360°	12-1001*
6 inch 360°	12-1002*
6 inch 180° pocket	12-1005*
6 inch 360° rulongmeter	12-1006*
3 inch -30° to 120° finger	12-1012*

available standard or with white Hi-Res® strip behind numbers (add HR to end of product code for Hi-Res® model)

Measurement Tolerance

This device measures inches and centimeters with a tolerance of ±0.04 inches (±1 millimeter) and degrees with a tolerance of ±1 degree.

Disposal Method

Dispose of item in accordance with the local/regional/national/ international regulations.



WARNING:

- · Clean and disinfect device before and after each patient use
- · Verify measurement markings are clearly visible · Ensure smooth operation of all moving parts
- Align device properly with anatomical landmarks
- · Apply gentle pressure during measurements
- Stop if patient reports pain or discomfort
- Store flat to prevent warping
- Replace if accuracy becomes compromised
- Do not attempt to bend or modify the device



Fabrication Enterprises Inc 250 Clearbrook Road, Suite 240 Elmsford, NY 10523 (USA) tel: +1-914-345-9300 * 800-431-2830 fax: +1-914-345-9800 * 800-634-5370 abEnt com





40213 Dusseldorf Germany



